



# Bois Artisanal



You can easily use a carpenter's square to draw an angle to be cut or even find the angle of just about any slope or roof pitch by placing a level against one of the edges.

This example shows a practical use where a skill saw would be used on parts that exceed the reach of a miter saw.



# Bois Artisanal



Length B	Length A	Angle
12	0.25	1.19
12	0.5	2.39
12	0.75	3.58
12	1	4.76
12	1.25	5.95
12	1.5	7.13
12	1.75	8.30
12	2	9.46
12	2.25	10.62
12	2.5	11.77
12	2.75	12.91
12	3	14.04
12	3.25	15.15
12	3.5	16.26
12	3.75	17.35
12	4	18.43
12	4.25	19.50
12	4.5	20.56
12	4.75	21.60
12	5	22.62
12	5.25	23.63
12	5.5	24.62
12	5.75	25.60
12	6	26.57
12	6.25	27.51
12	6.5	28.44
12	6.75	29.36
12	7	30.26
12	7.25	31.14
12	7.5	32.01
12	7.75	32.86
12	8	33.69
12	8.25	34.51
12	8.5	35.31
12	8.75	36.10
12	9	36.87
12	9.25	37.63
12	9.5	38.37
12	9.75	39.09
12	10	39.81
12	10.25	40.50
12	10.5	41.19
12	10.75	41.86
12	11	42.51
12	11.25	43.15
12	11.5	43.78
12	11.75	44.40
12	12	45.00

Length B	Length A	Angle
12	12.25	45.59
12	12.5	46.17
12	12.75	46.74
12	13	47.29
12	13.25	47.83
12	13.5	48.37
12	13.75	48.89
12	14	49.40
12	14.25	49.90
12	14.5	50.39
12	14.75	50.87
12	15	51.34
12	15.25	51.80
12	15.5	52.25
12	15.75	52.70
12	16	53.13
12	16.25	53.56
12	16.5	53.97
12	16.75	54.38
12	17	54.78
12	17.25	55.18
12	17.5	55.56
12	17.75	55.94
12	18	56.31
12	18.25	56.67
12	18.5	57.03
12	18.75	57.38
12	19	57.72
12	19.25	58.06
12	19.5	58.39
12	19.75	58.72
12	20	59.04
12	20.25	59.35
12	20.5	59.66
12	20.75	59.96
12	21	60.26
12	21.25	60.55
12	21.5	60.83
12	21.75	61.11
12	22	61.39
12	22.25	61.66
12	22.5	61.93
12	22.75	62.19
12	23	62.45
12	23.25	62.70
12	23.5	62.95
12	23.75	63.19
12	24	63.43